

Mouse and touch gestures

- To gesture with a mouse, hold down the right mouse button and drag in the gesture pattern.
- To gesture with a touchscreen or touchpad, touch with two fingers, pause, then drag in the gesture pattern. With a pen, touch and drag in the gesture pattern while holding the pen button.



Orienting

Spin

Modes

Sketch mode

Section mode

Up for the top tool