



Mouse and touch gestures

- **To gesture with a mouse**, hold down the right mouse button and drag in the gesture pattern.
- **To gesture with a touchscreen or touchpad**, touch with two fingers, pause, then drag in the gesture pattern. With a pen, touch and drag in the gesture pattern with the pen button pressed.
- **To cancel a gesture**, pause for one second.


General




Document commands




Sketch tools




Editing




Orienting




Insert tools




Detailing




Modes



Windows



Views



Intersect tools

